

Grain crusher „WALDNER FLOCKER“

Fix the wooden part (1) with the metal screw clamp (6) at an edge of a stable tabletop or working surface. Put the crank (3) to the metal pin (4) and turn the crank clock-wise.

With the screw (5) you can adjust the fineness of the flakes:

- If you turn the screw (5) clock-wise, you get fine flakes. If you turn it anti clock-wise, you get coarse flakes.
- Turn the screw (5) only when the crusher is empty.

