

# Parts Overview



For quick set up instructions, activate your phone camera and hover over code.

HOPPER PARTS	CHAMBER PARTS	BASE PARTS
Hopper Lid	Auger	Cord + Plug
Hopper	Strainer	
	Spinning Brush	Base
	Chamber	

### NOTE:

The chamber set (A) MUST be assembled separately BEFORE placing on top of the base (B).

CHAMBER SET	BASE
A	B

# Assembling the Chamber

### COMBINE AUGER, STRAINER + SPINNING BRUSH

Auger

Strainer (juice or smoothie strainer)

Spinning Brush

**STEP 1:** Place the auger into the strainer. Then place the combined auger and strainer into the spinning brush.

### PLACE COMPONENTS INTO CHAMBER

Large Wing

Small Wing

Large Cutout

Small Cutout

**STEP 2:** Locate the LARGE and SMALL WINGS on the outer rim of the strainer. Next, locate the corresponding LARGE AND SMALL CUTOUTS inside the chamber. Place the strainer set assembly into the chamber. Press the auger down firmly, so the top blade of the auger sits FLUSH with the top of the strainer.

# Assembling the Hopper

### ALIGN GUIDE MARK WITH UNLOCK SYMBOL

Hopper

Chamber

**STEP 1:** Align the vertical Guide mark on the hopper with the Unlock symbol on the chamber. Press hopper down to fit onto chamber. Be sure components are pressed into the chamber so the auger sits flush with the top edge.

### ROTATE HOPPER TO LOCK

Hopper

Chamber

**STEP 2:** Next, rotate the hopper clockwise until the Guide mark on the hopper is aligned with the Lock symbol on the chamber. If the hopper will not rotate to lock properly, please check to make sure the internal components of the chamber are assembled correctly.

# Final Assembly and Layering Guide

### FITTING CHAMBER SET ONTO BASE

Hopper Handle

Control Knob

**STEP 1:** Align the handle of the hopper vertically with the control knob on the base, and place the chamber set onto the base.

**STEP 2:** First insert the power cord into the back of the base and then the plug into the power outlet.

### LAYERING GUIDE

**STEP 3:** For best results, load your hopper as shown. Add soft or leafy foods first to the bottom and hard foods to the top to create a natural pressure that helps move the food through more easily. **Note: For safety, the lid must be securely closed for your juicer to turn on.**

ex. carrots, beets, ginger	HARD	TOP
ex. celery, melons, cucumber	MEDIUM	
ex. lemon, kiwi, pineapple	SOFT	
ex. spinach, lettuce, kale	LEAFY	BOTTOM

# Additional Tips

### HOPPER DISASSEMBLY

You must lift the chamber set from the base before you can unlock the chamber.

### LID REMOVAL

Hopper lid can be removed for cleaning.

### LID RELEASE

Squeeze the release tab to unlock the hopper lid.

### MAX FILL LINE

Do not fill ingredients past the maximum fill line on the hopper.

### PULP OUTLET LOOP

The pulp outlet loop can be rotated up to lock or downwards to unlock for cleaning.

### PLANT-BASED MILKS

For plant-based milks such as almond milk, it is best to add ingredients through the top hole in the hopper while the machine is ON.