



VIDIA PERSONAL BLENDER

USER MANUAL



Read this booklet thoroughly before using and save it for future reference

MODEL:PBL-001





IMPORTANT SAFEGUARDS

When using the electrical appliance, the following basic safety precautions must be followed:

1. Read all instructions.
2. Before using check that the voltage power corresponds to the one shown on the appliance nameplate.
3. Do not let the cord hang over edge of table or counter.
4. Do not place on or near a hot gas or electric burner, or in a heated oven.
5. Do not operate any appliance with a damaged cord or plug or after the appliance has malfunctioned or has been damaged in any manner. Return the appliance to the nearest authorized service facility for examination, repair or adjustment.
6. If the power cord is damaged it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
7. Don't touch any moving parts.
8. Do not leave foreign objects, such as spoons, forks, knives or the measuring cup, in the jug as this will damage the blades and other components when starting the machine and may cause injury.
9. The blades are sharp, so handle carefully.
10. The use of any attachment, including jug or jug lid, not recommended or sold by manufacturer may cause fire, electric shock or injury.
11. When making nut butters or oil-based foods, do not process for more than one minute. Over-processing can cause dangerous overheating.
12. When blending hot liquids or ingredients, use caution: spray or escaping steam may cause scalding and burns. Do not fill container



IMPORTANT SAFEGUARDS

to the maximum capacity. Always begin processing on the lowest speed setting. Keep hands and other exposed skin away from the lid opening to prevent possible burns.

13. Turn all controls to OFF and unplug the blender when it is not in use, before putting on or taking off parts, and before cleaning.

14. Never leave the appliance unattended while it is running.

15. To protect against risk of electrical shock do not put motor unit or power cord in water or other liquid.

16. Keep hands and utensils out of jug while blending. Failure to do this can cause severe injury to persons or damage to the blender.

17. If scraping is necessary, turn the power OFF, unplug from the electrical outlet, and use a rubber spatula only.

18. Always operate blender with lid in place.

19. Never put non-food items into the jug to blend.

20. Do not open the lid until the blade has completely stopped.

21. Do not put hands or other objects into jug during working.

22. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge only if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.

23. Children should be supervised to ensure that they do not play with the appliance.

24. Do not use outdoors.

25. Save these instructions.




HOUSEHOLD USE ONLY

KNOW YOUR BLENDER

Technical information

Product name: Vidia Personal Blender
Model: PBL-001
Warranty: 2 years
Weight: 2,5kg
Dimensions: approx. (cm) 37 x 14,5 x 15
Power: 230V~ 50Hz 1000W





ASSEMBLY INSTRUCTIONS

Assembly



Fig. 1




Fig. 2

Use




Fig. 3

Removal




Fig. 4




Fig. 5

Important:

Place the motor base on a clean, dry, and level surface such as a counter or table top.

1. Insert the plug into the power supply socket.
2. Pack the food material into the cup.



NOTE: Do not overfill! To avoid spilling, do not add ingredients past the "MAX" fill line.

3. Place the blade assembly onto the cup and twist it on tightly until you have a good seal.(Fig.1)



ASSEMBLY INSTRUCTIONS



CAUTION: The blade is very sharp, please handle carefully.

4. Turn the cup upside down and place it onto the motor unit, aligning the tabs on the cup with the motor unit . Turn it clockwise until you feel it click into place.(Fig.2)



NOTE: The appliance will not work if the jar is not assembled onto the motor unit properly.

5. Press one of the buttons to activate.(Fig.3)
6. To remove the cup, ensure that the motor has stopped running. Then turn cup counter clockwise (Fig.4) and pull straight up to remove.(Fig.5)
7. Turn the cup upright and remove the blade assembly by twisting the blade assembly counter clockwise. Be sure to store the blade assembly attached to an empty cup when not in use.
8. Twist the sip&seal lid onto the cup to enjoy your drink on the go. Press flip top cap firmly into the opening to get the best seal and prevent leaking. The flip top cap locks open when pressed backward.
9. Make sure that the motor base is unplugged when not in use.



OPERATING INSTRUCTIONS



Start/stop

Press once to start continuous operation. Press again to stop. Automatic stop after 60 seconds.

Auto Blend

Blends fresh or softer ingredients into a smooth consistency. Auto blend consists of a 3-second pulse followed by a 1-second break – this cycle is repeated 10 times. This works great for smoothies, and can be followed by high-speed (start/stop or pulse) blending if desired.

Pulse

Hold down the Pulse button for short bursts of blending. It is good for breaking up harder or bigger ingredients.



ADDITIONAL FUNCTIONS

Blending carrots

1. Place the appliance on a flat horizontal surface and make sure it is unplugged.
2. Cut the carrots into 15mm*15mm*15mm cubes. Put the carrot cubes along with purified water into the jug. The proportion of the carrot to water is 2:3. The total amount of the water mixture should not exceed the max level as indicated on the jug. Place the blade assembly onto the cup and twist it on tightly until you have a good seal.
3. Plug in the blender. Press the "Start/Stop" button.
4. Automatic stop after 60 seconds.



NOTE: The maximum cycle time of the blender is 60 seconds. The blender needs to rest between cycles, and after 10 cycles it must be allowed to cool down for a minimum of 10 minutes.

Crushing ice

1. Place the appliance on a flat horizontal surface and make sure it is unplugged.
2. Place a maximum of 10 ice cubes not exceeding 15 mm on any one side into the 700 ml cup. Place the blade assembly onto the cup and twist it on tightly until you have a good seal.
3. Plug in the blender. Press the "Start/Stop" button.
4. Allow at least 30 seconds for the ice to crush properly.



NOTE: The maximum cycle time of the blender is 60 seconds. The blender needs to rest between cycles, and after 10 cycles it must be allowed to cool down for a minimum of 10 minutes.



ADDITIONAL FUNCTIONS

Grinding coffee

1. Place the appliance on a flat horizontal surface and make sure it is unplugged.
Place 100g roasted coffee beans into the jug and close it tightly.
2. Note: Do not exceed 100g of coffee beans.
3. Plug in the blender. Press the “Start/Stop” button.
4. Allow at least 30 seconds for the best coffee consistency.



NOTE: The maximum cycle time of the blender is 60 seconds. The blender needs to rest between cycles, and after 10 cycles it must be allowed to cool down for a minimum of 10 minutes.



CLEANING AND MAINTENANCE

Running the blender for 30 seconds with clear water can help to clean the blender and blade assembly easily and rapidly in complete safety.

1. After use, remove the jar from the motor unit and rinse the jar under running water.
2. Wipe the outer surface of the motor unit with a damp cloth. Do not use abrasive cleanser. Never immerse in water or other liquid for cleaning.
3. All parts except the motor unit and jar base are dishwasher-safe. You can also wash those parts, except the motor unit and jar base, in warm, soapy water.
4. Dry all parts and then reassemble them. Store the appliance with the jug lid not completely closed to allow air to circulate and prevent odor.
5. If any problem has been encountered during use, never disassemble the motor unit by yourself. There are no user-serviceable parts inside. Contact only an authorized service facility for examination and repair.



NOTE: The jar base is not dishwasher-safe.



WARNING: The blade is very sharp. Handle carefully when cleaning. Do not use abrasive cleaners. Never immerse the motor unit in water for cleaning.



Please remember to follow local recycling laws and dispose of any electrical appliance in an environmentally-sensitive manner.



WARRANTY AND SERVICE

The Vidia PBL-001 personal blender is covered by the manufacturer's warranty for a period of 2 years from the date of purchase. This warranty covers normal household use only. Damage or malfunctions caused by using the product in any way other than that specified in this manual are not covered by the warranty.

In case of problems with the Vidia PBL-001 personal blender during the warranty period, contact the retailer or an authorized service center. There are no user-serviceable parts on this blender and any attempt to service it may be hazardous.

CE This product meets all the basic EU regulation requirements that relate to it. Changes to the text, design and technical specifications may occur without prior notice and we reserve the right to make these changes.



EUJUICERS.COM Ltd.
Rudolfovska 11
370 01 Ceske Budejovice
CZECH REPUBLIC
Phone: +420 775 584 237
email: info@eujuicers.com
www.eujuicers.com



HEALTHY RECIPES

Hydrating smoothie



The citric acid in green grapes speeds up the metabolism. Cucumbers are hydrating and cooling and help prevent fluid buildup and bloating. has diuretic effect and it prevents edema and controls blood pressure. The enzymes found in pineapple help digestion.

Ingredients

Green Grapes.....	1/2 Bunch
Cucumber.....	1/2
Pineapple	1/8
Melon.....	1/8
Lemon Juice.....	1 spoon
Ice	To Taste

Fountain of Youth


The antioxidants in tangerines provide an immunity boost to keep you healthier. Bell peppers are loaded with lycopene, a powerful antioxidant to keep you looking younger.

Ingredients

Tangerines.....	3 pieces
Red Bell Pepper.....	1/2



This image shows a single sheet of white paper with horizontal blue or grey ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.





www.vidiaproducts.com